

LINEWISE

Slip Joint Pole Jack



254-757-1177 | sales@line-wise.com | line-wise.com

SPECIFICATIONS & FEATURES

- Holds all the equipment needed to jack the pole sections together by supporting the cylinders on one end and the engine/hydraulic pump on the other.
- Lifted into place using a crane.
- Adjustable arms accommodate pole from 12”- 68” in diameter.
- Keeps Lineman safely away from the pole while in use
- Benefits of having the engine/hydraulic pump located in the box opposite from the cylinders:
 - Helps to counterbalance the weight of the cylinders on the arms.
 - Removes the problems associated with the gasoline engine/hydraulic pump out of the man basket (the potential for fire, hot engine parts, exhaust fumes, hydraulic oil leaks or hydraulic oil fluid injected into skin under pressure).



LineWise



INSPIRED BY LINEMEN TESTED BY LINEMEN TRUSTED BY LINEMEN



Material and specifications are subject to change without notice. Units in photos may include optional features. Contact a LineWise representative for available options. LineWise® and the LineWise logo are registered trademarks of Fritel & Associates, LLC and may not be used without permission.
© 2023 Diversified Product Development All Rights Reserved.



254-757-1177 | sales@line-wise.com | line-wise.com